TRAILBLAZE
BACKYARD ADVENTURE CO.

BACKYARD NINJA ADVENTURE COURSE

SETUP & PLAY GUIDE

Build strength. Boost confidence. Bring the adventure home.



AGES 5+

450 LB CAPACITY

SUPERVISED SHARED PLAY

OUTDOOR USE

WATCH THE SETUP VIDEO

Scan before you start.

Please read this guide fully before setup and keep for future reference.

TRAILBLAZE
BACKYARD ADVENTURE CO.

BEFORE YOU START

SAFE PLAY CHECKLIST

Follow this checklist to help ensure a safe and fun TrailBlaze adventure every time.

1



ADULT SETUP REQUIRED

Adults should set up, tension, and pack down the course.

2



ADULT SUPERVISION REQUIRED

Children must be supervised by an adult at all times during play.

3



AGES 5+

Suitable for children aged 5 years and over.

4



SUPERVISED SHARED PLAY

Multiple children may use separate obstacles under continuous adult supervision. Keep them safely spaced, with combined weight below 450 lb (204 kg).

5



START LOW

Set the line lower for beginners and increase challange gradually.

6



SOFT, CLEAR GROUND

Set up over soft, level ground and Keep the landing area clear.

7



CHECK BEFORE EVERY USE

Inspect the line, ratchet, straps, carabiners, and obstacles before play.

8



USE ONLY SUPPLIED PARTS

Use only the supplied or approved TrailBlaze parts and accessories.



ADULT USE ONLY

The ratchet must only be operated by an adult.

 ADULT SETUP ONLY

 RECOMMENDED ONE USER AT A TIME

 CHECK BEFORE EVERY USE

WHAT'S IN THE BOX

Check all parts before setup.

1 MAIN SETUP PARTS

10 obstacles + setup essentials

MAIN LINE+ RATCHET



TOP OBSTACLE LINE +Ratchet

x1

SLACKLINE



1" BOTTOM BALANCE LINE +Ratchet

x1

TREE PROTECTORS



TREE PROTECTORS

x4

HANGING BUCKLE STRAPS



BUCKLE STRAPS

x17

CARABINERS



CARABINERS

x17

2 8 OBSTACLE TYPES | 10 OBSTACLES TOTAL

1



MONKEY BARS

x2

2



GYM RINGS

x2

3



NINJA WHEEL

x1

4



SWING SEAT

x1

5



MONKEY FIST

x1

6



ROPE LADDER

x1

7



CARGO NET

x1

8



ARM TRAINER

x1

3 PREMIUM CARRY BAG



Durable drawstring bag to keep all parts organized and easy to carry.

x1

CHECK ALL PARTS

10 OBSTACLES INCLUDED

READY FOR SETUP


TRAILBLAZE
BACKYARD ADVENTURE CO.

BEFORE INSTALLATION

CHOOSE YOUR SETUP SPACE

Pick safe anchor points and a clear landing area before you install the line.

1 CHOOSE STRONG ANCHOR POINTS




Strong, mature trees or purpose-built, load-rated fixed posts.

Minimum tree diameter: 10 in / 25 cm

Use anchor points of similar height when possible.

2 CREATE A CLEAR PLAY ZONE




Keep at least 10 ft / 3 m clear around the course.






3 START LOW FOR BEGINNERS



Lower setups feel safer for beginners.

4 AVOID THESE LOCATIONS

Choose an open space away from hazards and obstacles.



Before installation: Review the Safe Play Checklist on Page 2 and check all parts on Page 3.

TRAILBLAZE
BACKYARD ADVENTURE CO.

STEP 1

INSTALL THE MAIN LINE

Wrap the tree protectors, attach both anchor points, and keep the line flat before tensioning.

1 WRAP TREE PROTECTORS

Wrap a tree protector around each anchor point at your chosen height and secure it firmly.



2 ATTACH MAIN LINE LOOP END

Wrap the non-ratchet end around the first tree and pass the loose end through the sewn loop.



3 FOLD THE LINE INTO A 'V'

As the line passes through the loop, fold the webbing into a V to help the line stay flatter and straighter before tensioning.



4 ATTACH RATCHET STRAP

Wrap the ratchet strap around the second tree over the tree protector and secure the ratchet end in place.



GOOD



Line is flat and untwisted.

NOT GOOD



Twisted line can cause uneven tension and is not safe.

TRAILBLAZE
BACKYARD ADVENTURE CO.

STEP 2

ADD HANGING STRAPS & THREAD THE RATCHET

Slide the hanging buckle straps onto the main line before feeding the line through the ratchet and tensioning it.


1 SLIDE ON HANGING STRAPS

Slide all hanging buckle straps onto the loose main line before final tensioning.



2 SPACE THEM OUT


Roughly position the straps where you want each obstacle to hang.



Important: Add all straps before tightening the line.

3 OPEN THE RATCHET

Open the ratchet fully so the main line can be threaded through the slot.



4 THREAD THE MAIN LINE

Feed the loose end of the main line through the ratchet slot, then pull it through by hand.



5 TENSION THE LINE

Pump the ratchet handle until the line feels firm and stable.



Adult setup only. Keep fingers clear.

6 CLOSE TO LOCK

Close the ratchet fully before use so the line is secure and ready for play.



Do not overfill the ratchet spool. Too much webbing around the spool can jam the ratchet and make it difficult to release.

ADD STRAPS FIRST | **PULL SLACK THROUGH BY HAND** | **CLOSE RATCHET BEFORE USE**


TRAILBLAZE
BACKYARD ADVENTURE CO.

STEP 3

CLIP ON OBSTACLES & CHECK YOUR COURSE

Once the line is fully tensioned and locked, clip each obstacle onto the hanging straps and do a final safety check before play.

1 ATTACH EACH OBSTACLE



! Clip obstacles on only after the line is fully tensioned and locked.

2 SUGGESTED COURSE LAYOUTS


BEGINNER COURSE

Closer spacing. Easier reach.




BALANCE COURSE

Mix of swings and grip challenges.




NINJA CHALLENGE

Wider spacing. Bigger challenge.



3 INSTALL THE BOTTOM BALANCE LINE

Install the 1" balance line below the obstacle line using the remaining tree protectors and ratchet. Keep it flat, tension it until firm, and close the ratchet fully before use.



CLIP ON LAST


CHECK EVERY CONNECTION

READY TO PLAY

FINAL SAFETY CHECK

1. Tree protectors are in place.
2. Ratchet is fully closed and locked.
3. Line is flat and untwisted.
4. Hanging straps are secure.
5. Carabiners are fully closed.
6. Obstacles are clipped on correctly.
7. Landing area is clear.
8. Apply adult weight gradually and check for slipping, sagging or movement before first use.

PACK DOWN, CARE & SUPPORT



TO RELEASE THE RATCHET

Adult use only. Hold the webbing securely. Pull and hold the release lever, open the ratchet fully to the flat release position, then allow the tension to release slowly.



AFTER USE

Remove all obstacles and accessories. Inspect all parts and store in a dry place.



CLEANING

Wipe straps, hardware and obstacles with a damp cloth.
Allow all parts to dry fully before storage.



INSPECT BEFORE EVERY USE

Do not use if any part is frayed, cracked, bent, rusted, loose or damaged.



For the longest product life take the course down during long periods of non-use, extreme weather or winter storage.
Store clean and dry in the carry bag.

PRODUCT INFORMATION

Model: TB015

Product: Backyard Ninja Adventure Course

Recommended Age: 5+

Capacity: 450 lb

Use: Outdoor backyard play

Made in China

Manufactured for:
Trailblaze Products LLC
539 W. Commerce blvd., Ste 1690,
Dallas, TX, 75208

Website:
www.trailblazeproducts.com

Support:
customercare@trailblazeproducts.com

Batch / Lot:_____

NEED HELP?

We're here to help!
Visit: https://trailblazeproducts.com/pages/contact
or email customercare@trailblazeproducts.com